

How to Find New Channels on your Digital TV

Note: The actual procedure for scanning for new channels is a bit different on each television, but here is a general guide that will give you the basics.

1. First, be sure an antenna is connected either to your television or your digital converter box.
2. Turn on the TV and press the “menu” button on your TV remote control, or on the converter box itself.
3. Go to “setup” or “settings.”
4. Look for a selection called “installation,” “system” or “channels”
5. Look for a choice labeled, “channel scan,” “program channels,” “Autoscan,” “Autoprogram” or “Autotuning” It maybe labeled something similar.
6. Select “enter” or “OK” to begin the scanning process.
7. When the TV indicates that scanning is complete, you can exit the menu. Often you can press the “menu” button to exit the setup.

Additional Note: You may wish to rescan from time to time to add any new channels that may have begun broadcasting in your area since your last scan.